

SECURITY SCREENS

CLEANING & CARE GUIDE

Security screens are built to be durable and low maintenance, but regular care is essential to keep them looking great and functioning properly.

How often you need to clean them depends on where you live. Homes near the coast, busy roads, or construction areas may require more frequent cleaning.

This simple guide will show you how to clean your screens and help extend their lifespan for years to come.

WHAT WILL YOU NEED?

Dish soap, water and a microfibre cleaning cloth.

FREQUENCY

Every 2-4 weeks

TYPE OF ENVIRONMENT

Tropical/Severe

HOW TO CLEAN YOUR SCREEN

STEP ONE

First, use a wet sponge or cloth to wash down the screen and the frame. This will loosen and remove any built up deposits of salts, dirt, and grime that may have collected on or around the screen. Keep a bucket handy and keep the sponge wet, to ensure you are simply spreading dust around.

STEP TWO

Next, wash the screen with a soft cloth and some detergent. Fibre brushes may be used to loosen dirt and grime, but abrasives such as sandpaper or emery paper must not be used. Where there has been greasy deposit, the surface should be washed with a white spirit using a soft cloth.

STEP THREE

Rinse well, with clean, fresh water.

STEP FOUR

Using the same solution as in **Step Two**, clean the tracks and the frames of the door. Use a soft bristle brush to clean any stubborn stains. Ensure that none of your cleaning solution enters the locking mechanism. The internal work of locks, handles, catches etc. should be kept in good working order by applying graphite powder **(do not use WD-40 as it attracts dust and will cause damage in the long term)** to any moving parts.

STEP FIVE

Rinse well.